



INSTALLATION INSTRUCTIONS (B-752)

115068 Rev 1, 9/24/2002
1-866-SWP-RACE (797-7223)
www.SW-Performance.com

Full Pillar Gauge Pod

WARNING: *Do not install Full Pillar in vehicle with side air bag curtains.*

SAFETY FIRST: Always wear safety glasses when working with tools.

1. These instructions are for installation of your new Full Pillar over the A-Pillar trim piece, but on some vehicles, complete replacement may be done with a few small changes.
2. Remove the A-Pillar trim piece. (It may be necessary to permanently remove any hand strap on the A-Pillar trim.)
3. Place the Full Pillar part in mounting position on the A-Pillar trim piece. Inspect fit to see if some trimming is necessary for a good fit.
4. (Optional) Paint the Full Pillar with paint that is safe for plastic.
5. Install gauges in the Full Pillar and make sure the wires can exit at the bottom. If clearance is not sufficient cut an opening in the A-Pillar trim piece near the bottom.
6. With the Full Pillar in mounting position on the trim piece, drill a 5/32" hole near each of the four corners of the Full Pillar on the flat surface area. Install the plastic nail retainers in each hole.
7. Place the Full Pillar in position on the A-Pillar and run the wires through the firewall (do not pinch wires) to the engine.
8. Secure the Full Pillar on the A-Pillar.