



## INSTALLATION INSTRUCTIONS (B-753)

115069 Rev 1, 9/24/2002  
1-866-SWP-RACE (797-7223)  
www.SW-Performance.com

### Dual & single Gauge Pod

---

**WARNING:** *Do not install Full Pillar in vehicle with side air bag curtains.*

**SAFETY FIRST:** Always wear safety glasses when working with tools.

1. Place the pod on the A-pillar trim in the exact location where it is to be mounted.
2. Mark this location on the A-pillar trim.
3. Remove the trim piece.
4. Drill an opening in the trim piece to allow room for the wiring.
5. (Optional) Paint the pod with paint that is safe for plastic.
6. Push the gauges into the pod and then place pod on trim piece to view wire clearance.
7. With the pod on the trim piece lined up with the location marks, drill a 5/32" hole near each corner on the flattest surface available. Push the plastic nails into each hole to install the gauge pod on the trim piece.
8. Run the gauge wires down the rear of the A-pillar and out through the firewall (do not pinch wires) to the engine.
9. Install the trim piece on the A-pillar.