



## INSTALLATION INSTRUCTIONS (B-759)

115276 Rev 1, 12/2/2002  
1-866-SWP-RACE (797-7223)  
www.SW-Performance.com

### Shift-Light and Alert-Light LED Kit Instructions

---

**SAFETY FIRST:** Always wear safety glasses when working with tools.

**NOTE:** This LED kit is not intended for the *ULTRA-SHIFT LIGHT*.

1. Using a T15 Torx driver, remove the mounting base screw and mounting base.
2. Using a T15 Torx driver, remove the two (2) rear cover screws and the rear cover.
3. Pull the wiring grommet out of the slot and push the inner bracket and light assembly out the front of the tube.
4. Once the assembly is removed from the tube, the old light kit may be removed from the bracket, and the new light kit may be installed.
5. Be sure that both the light kit, and the lens are captured by the bracket.
6. Insert the bracket and assembly into the front of the tube. Align the bottom hole in the tube with the screw clip on the bracket. Be sure to route the wire pigtail on the proper side of the bracket so it lines up with the slot in the tube.
7. Using a T15 Torx driver, install the mounting base but do not fully tighten at this point.
8. Fit the grommet into the slot in the tube and install the rear cover and tighten the two (2) screws to 4 in-lb.
9. Tighten the mounting base screw.
10. Reinstall the shift or alert light and test for proper operation.