



INSTALLATION INSTRUCTIONS (B-821)

117429 Rev 1, 1/8/2004
1-866-SWP-RACE (797-7223)
www.SW-Performance.com

Quad Console Pod

SAFETY FIRST: Always wear safety glasses when working with tools.

1. Gauge Pods are paintable to match the interior. Test fit the pod **BEFORE** painting, as the pod may not be returned after it has been painted.
2. Install all senders following the instructions provided with the instruments.
3. Remove the existing console and the shifter cover-plate.
4. Remove the front console cover or the original gauges where the new pod is to be installed.

CAUTION: When removing the factory gauges, they must be disconnected properly to avoid a short circuit or fire. Follow the manufacturer's specifications for safe removal.

5. Insert the gauges and complete the wiring/tubing connections to the gauges and route the wiring/tubing through the center console. Follow the instructions provided with the instruments for proper connections.
6. Using the supplied screws and hardware, install the new pod into the center console.

NOTE: Use caution when tightening the screws. If they are over-tightened, the pod may be damaged.

7. Reinstall the center console and the shifter cover-plate to complete the installation.