



INSTALLATION INSTRUCTIONS (B-822)

117430 Rev 1, 1/8/2004
1-866-SWP-RACE (797-7223)
www.SW-Performance.com

Steering Column Pod

SAFETY FIRST: Always wear safety glasses when working with tools.

1. Gauge Pods are paintable to match the interior. Test fit the pod **BEFORE** painting, as the pod may not be returned after it has been painted.
2. Install all senders and sender wiring or tubing and run to the steering column.
3. Depending on the pod, you will have to determine the best way to run the wiring, as some pods require a hole to be drilled into the stock column cover to run the wiring, and some have an area provided to run the wiring.
4. Cut off or unscrew the 2 gauge-mounting studs.
5. Insert the gauge and complete the wiring/hook-up to the gauge, following the gauge installation instructions.

CAUTION: When choosing a location for the pod, be sure that the pod does not interfere with any of the vehicle controls such as the turn signal, wiper control, cruise control, light control, hazard switch, gear selector, etc.

- 6-a. If using double sided tape, clean the inside of the pod and the outside of the column with alcohol, apply the double sided tape to the sides of the column, place the pod on top of the steering column and apply pressure at the tape areas to complete the installation.
- 6-b. If using the push rivets, place the pod on top of the column in the desired location, drill a 3/16" hole through the pod and the factory column cover on each side of the column. Press the rivets into position to complete the installation.