



INSTALLATION INSTRUCTIONS (B-754)

115070 Rev 1, 9/24/2002
1-866-SWP-RACE (797-7223)
www.SW-Performance.com

Instrument Bezel Pod

SAFETY FIRST: Always wear safety glasses when working with tools.

1. Install gauges into new bezel and test fit to assure clearance.
2. Connect installed gauges by running the wires down between dash and instrument cluster.
3. Clean factory bezel and the back of the gauge pod with glass cleaner where the double-sided tape will be applied.
4. Place the double-sided tape on the back of the pod and around the part that inserts into the original bezel. The tape may be cut and applied to several positions for the most secure mounting.
5. Peel backing from tape and install bezel. Align the bridge behind the steering column first and then front.
6. (Optional) Gauges requiring a compression fitting will need to use a "90 degree" fitting to clear the instrument cluster.