



## INSTALLATION INSTRUCTIONS (B-779)

113738 Rev 1, 1/13/2003  
1-866-SWP-RACE (797-7223)  
www.SW-Performance.com

### Shift Light Installation

**SAFETY FIRST:** Always wear safety glasses when working with tools.

**NOTE:** This shift light will only work with Stewart Warner Performance Memory/Shift-Light Tachometers. It will not work with the Standard Tachometer. If a shift light is desired with a Standard Stewart Warner Performance Tachometer, use the Ultra-Shift Light part number 114906.

#### **Shift-LIGHT MOUNTING:**

- The *Shift-Light* may be mounted, on a roll cage, steering column, dash, or existing tachometer.
- To mount the *Shift-Light* on the dash, use the supplied bracket and screw or rivet into place.
- To mount to a roll bar or steering column, use a hose clamp to secure.
- To mount on an existing tachometer, loosen the tachometer mounting strap and insert the base of the *Shift-Light* under strap and retighten the bolts.

#### **Shift-LIGHT CONNECTION:**

- Plug the Shift-Light into the connector at the rear of the tachometer (figure 1).

Figure 1

